




Einstellung der Ausgangsstromstärke über DIP-Schalter



I _{out}	Sw1	Sw2	Sw3
150mA	0	0	0
200mA	0	0	1
250mA	0	1	0
300mA	0	1	1
350mA	1	0	0
400mA	1	0	1
450mA	1	1	0
500mA	1	1	1