




Einstellung der Ausgangsstromstärke über DIP-Schalter



I _{out}	Sw1	Sw2	Sw3
350mA	0	0	0
400mA	0	0	1
450mA	0	1	0
500mA	0	1	1
550mA	1	0	0
600mA	1	0	1
650mA	1	1	0
700mA	1	1	1